

■ CUSTOMIZED BODY ELECTRONICS SYSTEM

An intelligent tester II can change the specification of the systems or functions.

System	Intelligent Tester II Display Content	Content	Default	Selection
Wireless Door Lock Remote Control System	Open Door Warning* ¹	Function to make the buzzer sound for 10 seconds if the door is open when locking with the wireless door lock function.	ON	ON/OFF
	Wireless Control	Function to turn ON/OFF of the wireless door lock.	ON	ON/OFF
	Hazard Answer Back (Hazard answer back of the wireless)	Function to turn ON/OFF of the hazard answer back of the wireless door lock.	ON	ON/OFF
	Auto Lock Time	Function to change the time until relocking after unlocking with the wireless door lock.	30 s	30 s/ 60 s
	Wireless Buzzer Resp* ¹	Function to turn on/off of the wireless buzzer response function.	ON	ON/OFF
Illuminated Entry System	Lighting Time	Function to change the lighting time after closing the door. (It will quickly fade out in case of selecting the power source mode to IG-ON.)	15 s	7.5 s/ 15 s/ 30 s
	Illumination System	Function to light up the front interior light, key illumination and foot light when one of the following occurs; power source mode IG-ON, door unlocked or door open.	ON	ON/OFF
	Light Control	Function to light up the front interior light, key illumination and foot light when the power source mode is IG-ON and the shift position is not P.	ON	ON/OFF
	I/L ON W/Unlock (Interior light ON w/door key unlock)	Function to light the interior light, etc. when the door is unlocked with a transmitter, door key or door lock control switch.	ON	ON/OFF
	I/L when ACC OFF (Light the I/L when ACC OFF)	Function to light the interior light when the power source mode is selected from “ACC” to “OFF”.	ON	ON/OFF
Warning	Key Low Battery Warning* ¹ (Warn when the key battery becomes low)	Function to set a warning function for the first time when a key battery becomes low.	ON	ON/OFF
	Key Remind Sound	Function to change the frequency of the key reminder buzzer.	Normal	Normal/ Fast/ Slow/ 0 s
	Seat Belt Warning	Function to change the seat-belt warning buzzer.	D/P ON	D/P ON/ D ON/ P ON/ D/P OFF

*¹: Only for Models with Smart Entry & Start System

(Continued)

System	Intelligent Tester II Display Content	Contents	Default	Selection
Light Control	Sensitivity (Turn ON luminous intensity)	Function to adjust the sensitivity of the lighting illumination.	Normal	Light2/ Light1/ Normal/ Dark1/ Dark 2
	Response Time	Function to change the delay timing of lighting the taillight when going into the tunnel in case that the light control switch is at AUTO position.	Normal	Normal/ Long
	DRL Function	Function to turn on/off of the DRL function.	ON	ON/OFF
Air Conditioning* ¹	Set Temperature Shift	Function to control with the shifted temperature against the display temperature.	Normal	+2°C/ +1°C/ Normal/ -1°C/ -2°C
	Air Inlet Mode	In case of turning the A/C ON when you desire to make the compartment cool down quickly, this is the function to change the mode automatically to RECIRCULATED mode.	Auto	Manual/ Auto
	Compressor/Air Inlet DEF Operation	Function to turn the A/C ON automatically linking with the FRONT DEF button when A/C OFF.	Link	Normal/ Link
	Evaporator Control	Function to set the evaporator control to the AUTOMATIC position (AUTO) to save power or to the coldest position (MANUAL) to dehumidify the air and to prevent the windows fogging up.	Auto	Manual/ Auto
	Foot/DEF Automatic Blow Up Function	Function to switch the blower level automatically when the defroster is ON.	ON	ON/OFF
	Foot/DEF Auto Mode	Function to turn the air flow from FOOT/DEF ON automatically when AUTO MODE is ON.	ON	ON/OFF
	Ambient Temperature Shift	Function to control with the shifted ambient temperature against the display ambient temperature.	Normal	+3°C/ +2°C/ +1°C/ Normal/ -1°C/ -2°C/ -3°C
Smart Entry & Start System* ²	Select IG ON Available Area	Function to choose the available area for smart key to start E/G and cancel the steering lock.	All	Front/ All
	Park Wait Time	Function to set a wait time to permit opening a door after it being locked.	3.0 s	1.0 s/2.0 s/ 3.0 s/5.5 s

*¹: Only for Models with Automatic Air Conditioning

*²: Only for Models with Smart Entry & Start System