

■ DIAGNOSIS

If a malfunction occurs on CAN communication line, the ECU that is connected to CAN communication line stores the DTCs (Diagnostic Trouble Codes) in its memory.

- There are 2-digit DTCs and 5-digit DTCs for CAN communication.
- The 5-digit DTCs can be read by connecting an intelligent tester II to the DLC3.
- The 2-digit DTCs can be read by connecting the SST (09843-18040) to TC and CG terminals of the DLC3.

For details, see the RAV4 Repair Manual (Pub. No. RM01N0E).