


Position of Parts in Instrument Panel <LHD>



- * 1:w/o Entry & Start System
w/o Engine Immobiliser System
- * 2:w/o Entry & Start System
w/ Engine Immobiliser System
- * 11:Before Dec. 2008 Production Europe

Position of Parts in Instrument Panel <LHD>

- E 1 Power Heater SW
- E 2 Light Control Rheostat
- E 3 Headlamp Leveling SW
- E 4 Headlamp Cleaner SW
- E 5 Ignition SW
- E 6 Steering Lock ECU
- E 7 Ignition Key Cylinder Lamp
- E 8 Transponder Key Amplifier
- E 9 Unlock Warning SW
- E 10 Spiral Cable
- E 11 Airbag Squib (Steering Wheel Pad)
- E 12 Windshield Wiper SW Assembly
- E 13 Windshield Wiper SW Assembly
- E 14 Steering Sensor
- E 15 Headlamp Dimmer SW Assembly
- E 16 DLC3
- E 18 Main Body ECU
- E 19 Main Body ECU
- E 20 Main Body ECU

Position of Parts in Instrument Panel <LHD>

