




























Position of Parts in Instrument Panel <LHD>



Position of Parts in Instrument Panel <LHD>


- E 70 Air Inlet Control Servo Motor
- E 71 Short Connector
- E 72 Short Connector
- E 73 Junction Connector
- E 74 Junction Connector
- E 75 Junction Connector
- E 76 Junction Connector
- E 77 Junction Connector
- E 78 Diode (Rear Wiper)
- E 79 Junction Connector
- E 80 Junction Connector
- E 90 Radio Receiver Assembly
- E 91 Radio Receiver Assembly
- E 92 Radio Receiver Assembly
- E 93 Diode (Heater)
- E 95 Steering Sensor
- E 96 VSC OFF SW
- E 97 Junction Connector
- E 98 Transmission Control SW
- E 99 Front Wiper Deicer SW
- E 100 No.1 Stereo Jack Adapter Assembly
- E 101 No.1 Pattern Select Switch Assembly
- E 104 Headlamp Cleaner SW
- E 105 Heated Oxygen Sensor (Bank 1 Sensor 2)
- E 106 Navigation Receiver Assembly
- E 107 Radio Receiver Assembly
- E 108 Clock
- E 109 Integration Control and Panel Assembly
- E 111 Junction Connector
- E 115 Junction Connector
- E 116 Blower Motor
- E 117 Blower Resistor
- E 118 A/C Room Temp. Sensor
- E 119 4WD Control SW

Position of Parts in Instrument Panel <LHD>




Position of Parts in Instrument Panel <LHD>


E111
Gray




E115
Gray



E116
White



E117
White



E118
White



E119
White

