


Position of Parts in Instrument Panel <RHD>



* 1:LH Turn Lever Type
 * 2:RH Turn Lever Type

Position of Parts in Instrument Panel <RHD>

- E 2 Light Control Rheostat
- E 3 Headlamp Leveling SW
- E 5 Ignition SW
- E 6 Steering Lock ECU
- E 8 Transponder Key Amplifier
- E 9 Unlock Warning SW
- E 10 Spiral Cable
- E 11 Airbag Squib (Steering Wheel Pad)
- E 12 Windshield Wiper SW Assembly
- E 13 Windshield Wiper SW Assembly
- E 14 Steering Sensor
- E 15 Headlamp Dimmer SW Assembly
- E 16 DLC3
- E 18 Main Body ECU
- E 19 Main Body ECU
- E 20 Main Body ECU

Position of Parts in Instrument Panel <RHD>

