


Position of Parts in Instrument Panel <RHD>




**Position of Parts in Instrument Panel <RHD>**

---


- E 41 A/C Amplifier
- E 42 A/C Amplifier
- E 43 A/C Amplifier
- E 44 Shift Lock Control ECU
- E 45 Transmission Control SW
- E 46 Parking Brake SW
- E 47 Outer Mirror SW
- E 48 Power Outlet Socket (Front)
- E 49 Airbag Sensor Assembly Center
- E 50 Transponder Key ECU
- E 51 ID Code Box
- E 52 Navigation Receiver Assembly
- E 53 Navigation Receiver Assembly
- E 54 Navigation Receiver Assembly
- E 55 Antenna Amplifier
- E 56 Navigation Receiver Assembly
- E 57 Navigation Receiver Assembly
- E 58 4WD Control SW
- E 60 Blower Motor
- E 61 Blower Motor
- E 62 Blower Resistor
- E 63 Certification ECU
- E 64 Tire Pressure Warning ECU and Receiver
- E 65 Tire Pressure Warning ECU and Receiver
- E 66 Auto Wiper Relay
- E 67 4WD Control ECU
- E 68 Airbag Cut Off SW
- E 69 A/T Shift Lever Illumination

Position of Parts in Instrument Panel <RHD>


E 41  
White




E 42  
White




E 43  
White



E 44  
White




E 45  
White




E 46  
Black




E 47  
White




E 48  
White




E 49  
Yellow




E 50  
White



E 50  
Black




E 51  
White




(Before Aug. 2010 Production)

(From Aug. 2010 Production)


E 52  
White



E 53  
White




E 54  
White



E 55  
White




E 56  
White




E 57  
Gray



E 58  
Black



E 60  
Black



Position of Parts in Instrument Panel <RHD>

