


Position of Parts in Instrument Panel <RHD>



- \* 7:Except Australia
- \* 8:Australia
- \* 9:Before Aug. 2008 Production Except Europe, Before Dec. 2008 Production Europe
- \* 10:From Aug. 2008 Production Except Europe, From Dec. 2008 Production Europe
- \* 13:From Dec. 2008 Production Diesel Cold Area Spec. Except A/T
- \* 14:w/ PTC Heater Except \*13
- \* 29:Before Feb. 2010 Production
- \* 30:From Feb. 2010 Production

**Position of Parts in Instrument Panel <RHD>**

---

- A 1 Cruise Control Clutch SW
- A 2 Power Steering ECU
- A 3 Brake Pedal Load Sensing SW
- A 4 Clutch Start SW
- A 5 Stop Lamp SW
- A 6 Accelerator Position Sensor
- A 7 Option Connector
- A 29 PTC Heater
- A 30 PTC Heater
- A 50 Junction Connector
- A 51 Junction Connector
- A 52 Junction Connector
- A 53 Junction Connector
- A 59 Option Connector
- A 66 Stop Lamp SW
- A 68 PTC Heater
- A 69 PTC Heater
- A 70 Stop Light Control Relay
- A 71 Junction Connector
- A 72 Junction Connector
- A 80 Junction Connector

Position of Parts in Instrument Panel <RHD>

