

# System Outline

---

## **1.Manual Lock & Unlock Function**

All the doors (Including the back door) are locked or unlocked by operating the door lock control switch (For manual operation) to 'lock' or 'unlock' side.

## **2.Key Confinement Prevention Function**

To prevent the key from being locked in the cabin, this system prevents the doors from being locked via the door lock control switch (manual operation or key-linked) or the door lock knob if the key is still in the ignition key cylinder and the driver's door is open.

## **3.Door Lock Security Function**

When a lock operation is activated via the wireless remote control, the door security function is set to prevent the door lock control switch from unlocking the doors.